



Disney  
**FROZEN**



Disney  
**FROZEN**



◀ **DPAA038C05** 42 □ 17 - 120  
CHARNIÈRES FLEX / FLEX HINGES



◀ **DPAA038C10** 42 □ 17 - 120  
CHARNIÈRES FLEX / FLEX HINGES



◀ **DPAA038C11** 42 □ 17 - 120  
CHARNIÈRES FLEX / FLEX HINGES



ACÉTATE / ACETATE



Disney  
**FROZEN**



◀ **DPAA039C08** 44 □ 15 - 120  
CHARNIÈRES FLEX / FLEX HINGES



◀ **DPAA039C10** 44 □ 15 - 120  
CHARNIÈRES FLEX / FLEX HINGES



◀ **DPAA039C11** 44 □ 15 - 120  
CHARNIÈRES FLEX / FLEX HINGES



ACÉTATE / ACETATE



Disney  
**FROZEN**



◀ **DPAA040C10** 46 □ 15 - 130  
CHARNIÈRES FLEX / FLEX HINGES



◀ **DPAA040C12** 46 □ 15 - 130  
CHARNIÈRES FLEX / FLEX HINGES



◀ **DPAA040C14** 46 □ 15 - 130  
CHARNIÈRES FLEX / FLEX HINGES



ACÉTATE / ACETATE



Disney  
**FROZEN**



◀ **DPAA041C05** 47 □ 15 - 130  
CHARNIÈRES FLEX / FLEX HINGES



◀ **DPAA041C11** 47 □ 15 - 130  
CHARNIÈRES FLEX / FLEX HINGES



◀ **DPAA041C12** 47 □ 15 - 130  
CHARNIÈRES FLEX / FLEX HINGES



ACÉTATE / ACETATE